

**BRITISH WIRING INC.**

P.O. BOX 185

617 WALNUT STREET

BALLY, PA 19503

Toll Free: 866-461-9050

Fax: 610-845-3518

[e-mail: britishwiring@ameritech.net](mailto:britishwiring@ameritech.net)[web page: www.britishwiring.com](http://www.britishwiring.com)

	Wire	Wrap	cription
	B	B	Braided wire and Braid outer wrap.
	P	P	PVC wire and PVC tape outer wrap.
	P	B	PVC wire and Braid outer wrap.
	PB	B	Mixture of PVC & Braided wire & Braid outer wrap.

**Alternator Conversion**

<b>ALT</b>	-	-	<b>All</b>	<b>Any model, factory conversion of harness from generator to alternator.</b>
------------	---	---	------------	---

**Series 1 LHD Harnesses - Note: adding turn signal wiring is a special order**

Part #	Wire	Wrap	Pcs	Year	Model, Series, Chassis # and Identifying Features
LR101 BB	B	B	4	48 - 49	Short wheel base, 80" chassis, <b>86 0001 to 610 5830</b> 1.6 L petrol engine, RF96 regulator, separate fuse box
LR101 PB	P	B			
LR102 BB	B	B	4	49 - 50	Short wheel base, 80" chassis, <b>610 5831 to 611 1546</b> 1.6 Litre petrol engine, RF95 regulator
LR102 PB	P	B			
LR103 BB	B	B	4	50 - 51	Short wheel base, 80" chassis, <b>611 1547 to 1610 3898</b> 1.6 Litre petrol engine, fitted with 7" headlamps,
LR103 PB	P	B			
LR104 BB	B	B	6	51 - 53	Short wheel base, 80" chassis, <b>1611 3898 - on &amp; 2610 0001 - on</b> 1.6 & 2 L petrol engine, RB106 regulator, separate fuse box,
LR104 PB	P	B			
LR106 BB	B	B	6	53 - 55	Short wheel base, 86" chassis, <b>4710 0001 - on</b> 2 L petrol engine.
LR106 PB	P	B			
LR108 BB	B	B	8	56 - 58	Short wheel base, 88" chassis, (LWB, special order) <b>1216 00001 - on</b> 2 L petrol engine, dip switch on floor, horn on bulkhead
LR108 PB	P	B			
LR109 BB	B	B	1	53 - 58	<b>Indicator harness</b> for station wagon, short wheel base, 86" & 88" chassis, Incorporates brake lights
LR109 PB	P	B			
LR110 BB	B	B	10	All	Series 1, Short wheel base, <b>Diesel Engine</b>
LR110 PB	P	B			

**Series 1 Optional Harnesses**

SC63	P	B	1	48 - 55	Steering column harness for 80"- 86" chassis vehicles, not for 88" chassis.
LR112 BP	B	P	2	50 - 51	Headlamp lead set for Series 1 harness (80" chassis) 611 1547 - on <b>For LR103 only - no headlamp plugs installed - bare wires on one end</b>
LR112 PP	P	P			
BW112 BP	B	P	2	50 - 51	Headlamp lead set for Series 1 harness (80" chassis) 611 1547 - on <b>For LR103 only - has sealed beam headlamp plugs installed</b>
BW112 PP	P	P			
LR113 BX	B	PB	2	51 - 58	Headlamp/sidelamp lead set for Series 1 (80"- 88" chassis) 1611 3898 - on <b>For LR104, 106 &amp; 108 -no headlamp plugs installed, no turn signals wires</b>
LR113 PX	P	PB			
BW113 BX	B	PB	2	51 - 58	Headlamp/sidelamp lead set for Series 1 (80"- 88" chassis) 1611 3898 - on <b>For LR104, 106 &amp; 108 -has sealed beam headlamp plugs, no turn signals</b>
BW113 PX	P	PB			

**Series 1 Optional Harnesses continued on next page**

Series 1 Optional Harnesses (continued)					
Part #	Wire	Wrap	Pcs	Year	Model, Series, Chassis # and Identifying Features
LR115 BX	B	PB	2	51 - 58	Headlamp/sidelamp lead set for Series 1 (80"- 88" chassis) 1611 3898 - on <b>For LR104, 106 &amp; 108 -no headlamp plugs, has turn signal pigtails</b>
LR115 PX	P	PB			
BW115 BX	B	PB	2	51 - 58	Headlamp/sidelamp lead set for Series 1 (80"- 88" chassis) 1611 3898 - on <b>For LR104, 106 &amp; 108 -sealed beam headlamp plugs &amp; turn signal pigtails</b>
BW115 PX	P	PB			
BW76 PB	P	B	1	51 - 58	Indicator switch and indicator warning light sub-harness. Used when turn signal wires are ordered with the main and body harnesses.
BW76 PP	P	P			
LR114 BP	B	P	2	51 - 58	Tow bar harness, extends park and brake lights to tow. For LR104, LR106 & LR108
LR114 PP	P	P			
LR114 FC	P	B	2	51 - 58	Tow bar harness, extends turn signal wires as well as park and stop light wires
BC49	B	-	4	48 - 58	Petrol Engine, Battery cable set, Positive Earth
BC50	B	-	4	48 - 58	Petrol Engine, Battery cable set, Negative Earth
BC48	B	-	4	up to 58	Diesel Engine, Battery cable set
HT21	P	-	5	All Yrs	Spark plug wire set for all 4 cylinder models

Series 2 Main Harnesses - 4 cylinder					
Part #	Wire	Wrap	Pcs	Year	Model, Series, Chassis # and Identifying Features
LR201 BB	B	B	7	58 - 61	<b>PETROL</b> engine - main & body harnesses, state SWB or LWB, 1418 00001 - on <b>2 L,</b> positive earth, generator, turn signal wires included
LR201 PB	P	B			
LR210 BB	B	B	8	58 - 61	<b>DIESEL</b> engine - main & body harnesses, state SWB or LWB, 1418 00001 - on <b>2 Litre,</b> positive earth, generator, turn signal wires included
LR210 PB	P	B			
LR211 BB	B	B	7	58 - 61	<b>DIESEL</b> engine - main & body harnesses, state SWB or LWB, 1418 00001 - on <b>2.25 L,</b> positive earth, generator, turn signal wires included
LR211 PB	P	B			
Series 2 Optional Harnesses					
LR220 BX	B	PB	2	58 - 61	Set (2) of sidelamp, turn signal, headlamp pigtails for headlamps in GRILL <b>No headlamp plugs installed</b> - bare wires on one end of headlamp pigtails
LR220 PX	P	PB			
BW220 BX	B	PB	2	58 - 61	Set (2) of sidelamp, turn signal, headlamp pigtails for headlamps in GRILL <b>Has headlamp plugs installed</b> for sealed beam headlamps on H/L pigtails
BW220 PX	P	PB			
C 143	-	-	2	58 - 61	Lucas 2 way fuse box for glass fuses. Has terminals and cover, fuses are separate.
HT21	P	-	5	58 - 61	Spark plug wire set, 4 cylinder models.
LR114 FC	P	B	2	58 - 61	Tow bar harness, extends turn signal wires as well as park and stop light wires

Series 2A Main Harnesses - 4 cylinder - Suffix A through C					
Part #	Wire	Wrap	Pcs	Year	Model, Series, Chassis # and Identifying Features
LR202 PB	P	B	5	61 - 65	<b>Petrol Main</b> for both SWB & LWB, 24,100,001A up to & including suffix C 2.25 L, <b>positive earth</b> , generator, ammeter, takes 1488 or 1489 body harness
LR202 PP	P	P			
LR212 PB	P	B	7	61 - 65	<b>Diesel Main</b> for both SWB & LWB, 24,100,001A up to & including suffix C. 2.25 L, <b>positive earth</b> , generator, ammeter, takes 1488 or 1489 body harness
LR212 PP	P	P			
LR204 PB	P	B	3	-65-	<b>Petrol Main</b> for both SWB & LWB Early <b>alternator</b> with separate control box, takes 1488 or 1489 body harness
LR204 PP	P	P			
Series 2A Body Harnesses - 4 cylinder - Suffix A through C					
1488 PB	P	B	1	61 - 65	<b>Body harness, SWB - 88"</b> , to fit main harnesses above
1488 PP	P	P			
1489 PB	P	B	1	61 - 65	<b>Body harness, LWB - 109"</b> , to fit main harnesses above
1489 PP	P	P			

Series 2A Optional Harnesses - 4 cylinder - Suffix A through C					
Part #	Wire	Wrap	Pcs	Year	Model, Series, Chassis # and Identifying Features
LR220 PX	P	PB	2	61 - 65	Set (2) of sidelamp, turn signal, headlamp pigtailed for headlamps in GRILL <b>No headlamp plugs installed</b> - bare wires on one end of headlamp pigtailed
BW220 PX	P	PB	2	61 - 65	Set (2) of sidelamp, turn signal, headlamp pigtailed for headlamps in GRILL <b>Has headlamp plugs installed</b> for sealed beam headlamps on H/L pigtailed
C 143	-	-	2	61 - 65	Lucas 2 way fuse box for glass fuses. Has terminals and cover, fuses are separate.
HT21	P	-	5	61 - 65	Spark plug wire set, 4 cylinder models.
LR223	P	B	2	61 - 65	Tow bar harness, extends turn signal wires as well as park and stop light wires

Series 2A Main Harnesses - 4 cylinder - Suffix D through H					
LR203 PB	P	B	5	66 - 71	<b>Petrol Main</b> for both SWB & LWB, <b>Suffix D upto &amp; including Suffix H</b> , 2.25 L, <b>negative earth</b> , generator, takes 1488 or 1489 body harness
LR203 PP	P	P			
LR213 PB	P	B	8	66 - 71	<b>Diesel Main</b> for both SWB & LWB, <b>suffix D up to &amp; including suffix H</b> , 2.25 L, <b>negative earth</b> , generator, takes 1488 or 1489 body harness
LR213 PP	P	P			

Series 2A Body Harnesses - 4 cylinder - Suffix D through H					
--	--	--	--	--	--

1488 PB	P	B	1	66 - 71	<b>Body harness, SWB - 88"</b> , to fit main harnesses above
1488 PP	P	P			
1489 PB	P	B	1	66 - 71	<b>Body harness, LWB - 109"</b> , to fit main harnesses above
1489 PP	P	P			

Series 2A Optional Harnesses - 4 cylinder - Suffix D through H					
LR220 PX	P	PB	2	66 - on	Set of sidelamp, turn signal, headlamp pigtailed (2) for headlamps in <b>GRILL</b> <b>No headlamp plugs installed</b> - bare wires on one end of headlamp pigtailed
BW220 PX	P	PB	2	66 - on	Set of sidelamp, turn signal, headlamp pigtailed (2) for headlamps in <b>GRILL</b> <b>Has headlamp plugs installed</b> for sealed beam headlamps on H/L pigtailed
LR221	P	PB	2	up to 71	Set of sidelamp, turn signal, headlamp pigtailed (2) for headlamps in <b>WINGS</b> <b>No headlamp plugs installed</b> - bare wires on one end of headlamp pigtailed
BW221	P	PB	2	up to 71	Set of sidelamp, turn signal, headlamp pigtailed (2) for headlamps in <b>WINGS</b> <b>Has headlamp plugs installed</b> for sealed beam headlamps on H/L pigtailed
C 143	-	-	2	61 - 65	Lucas 2 way fuse box for glass fuses. Has terminals and cover, fuses are separate.
LR222	P	P	1	69 - on	Wiper motor sub-harness for two speed wiper motor.
1493 PB	P	B	1	69 - on	Ignition switch sub-harness
1493 PP	P	P			
HT21	P	-	5	66 - 70	Spark plug wire set, 4 cylinder models.
LR223	P	B	2	66 - 70	Tow bar harness, extends turn signal wires as well as park and stop light wires

Series 2A Harnesses, 6 CYLINDER Petrol Engine, NADA					
Part #	Wire	Wrap	Pcs	Year	Model, Series, Chassis # and Identifying Features
LR261	PB	B	2	-67	LWB Main and Body, 345 - <b>upto suffix E</b> , 6 Cylinder models with generator
LR262	PB	B	2	67 - 68	LWB Main and Body, all 345 - <b>suffix F</b> , 6 Cylinder models with generator
LR263	PB	B	2	67 - 68	LWB Main and Body, 345 - <b>suffix G on</b> , 6 Cylinder models with generator

LIGHTWEIGHTS Series 2, 2A and 3					
Part #	Wire	Wrap	Pcs	Year	Model, Series, Chassis # and Identifying Features
LR241	P	P	8		LHD Series 2 & 2A, with 6 way light switch and twin tanks
LR310	P	P	3		LHD Series 3, with series 2 bulkhead & 6 way light switch & military wiring
HT21	P	-	5	All Yrs	Spark plug wire set, 4 cylinder models.

<b>Series 3 LHD Harnesses - LR302 (main), LR323 (engine) &amp; LR334 (body)</b>						
<b>harnesses fit the vast majority of Series 3 imported to the US</b>						
<i>Part #</i>	<i>Wire</i>	<i>Wrap</i>	<i>Pcs</i>	<i>Year</i>	<i>Model, Series, Chassis # and Identifying Features</i>	
LR302	P	P	1	71 - 80	<b>Main</b> for 2.25 & 2.6L <b>petrol</b> engine with choke thermostat warning switch LR# 575408	
LR304	P	P	1	to 8/80	<b>Main</b> for 2.25 & 2.6L <b>petrol</b> engine <b>without</b> choke thermostat warning switch LR# PRC 1332	
LR306	P	P	1	9/80 to 1/83	<b>Main</b> for 2.25 L <b>petrol</b> engine with rear fog & reverse lights LR# PRC 2531	
LR312	P	P	1	to 1/83	<b>Main</b> for <b>V8</b> petrol LR# PRC 2005 & 2634	
LR318	P	P	1	9/80 to 11/83	<b>Main</b> harness for <b>diesel</b> engine LHD, with rear fog & reverse lights LR# PRC 1349 & 2534	
LR322	P	P	1	12/83 on	<b>Main</b> harness for <b>diesel</b> engine LHD, with rear fog & reverse lights LR# PRC 4102	
<b>Series 3 "Engine" Harness (services the engine itself)</b>						
LR323	P	P	1	71 - 80	<b>"Engine"</b> harness, petrol with choke thermostat warning switch LR# 589033	
LR324	P	P	1	to 8/80	<b>"Engine"</b> harness, petrol, <b>up to engine suffix A</b> without choke thermostat warning switch LR# 589851	
LR325	P	P	1	9/80-on	<b>"Engine"</b> harness, petrol, <b>engine suffix B - on</b> LR# 623087	
LR326	P	P	1	to 6/82	<b>"Engine"</b> harness for <b>V8</b> petrol engine LR# PRC 1939	
LR331	P	P	1		<b>"Engine"</b> harness for 2.25L <b>diesel</b> engine suffix A - on LR# 589034	
LR332	P	P	1		<b>"Engine"</b> harness for 2.25L <b>diesel</b> engine suffix B - on LR# 623088	
LR333	P	P	1		<b>"Engine"</b> harness for 2.25L <b>diesel</b> engine suffix C - on LR# PRC 1001	
<b>Series 3 Body Harness</b>						
LR334	P	P	1	71 - 80	<b>Body</b> harness for <b>SWB 88"</b> , has wire for low fuel LR# 589705 & 589708	
LR335	P	P	1	71 - 80	<b>Body</b> harness for <b>LWB 109"</b> , has wire for low fuel LR# 589707 & 589709	
LR336	P	P	1		<b>Body</b> harness for <b>SWB 88"</b> , <b>station wagon</b> , has rear fogs, spot and reversing lights, LR# PRC2671	
LR337	P	P	1		<b>Body</b> harness for <b>LWB 109"</b> , <b>station wagon</b> , has rear fog, spot & reverse lights LR# 589710 & PRC2672	
<b>Series 3 Other Harnesses</b>						
LR396	P	P	1	All	Wiring for two speed heater, Petrol & Diesel	
LR399	P	P	1	All	Wiring for hazard warning light switch and relay, Petrol & Diesel	
LR340	P	P	1	All	Brake failure warning harness	
LR339	P	P	1	All	Tow bar harness	
LRA109	-	-	1	All	Four way fuse box	
BC324	EB	-	1		Petrol 2.6L - Engine to chassis earth cable LR# 589878	
BC303	EB	-	1		Petrol (All) - Battery to earth (ground) cable LR# 623210	
BC301	P	P	1		Petrol 2.25L - Battery to solenoid cable LR# PRC1106	
BC302	P	P	1		Petrol 2.25L - Solenoid to starter cable LR# PRC1551	
BC313	EB	-	1		Diesel 2.25L - battery to earth (ground) cable LR# 589872	
BC314	EB	-	1		Diesel 2.25L - battery to solenoid cable LR# 90575183	
HT21	P	-	5	All Yrs	Spark plug wire set, 4 cylinder models.	

<b>Range Rover</b>						
<i>Part #</i>	<i>Wire</i>	<i>Wrap</i>	<i>Pcs</i>	<i>Year</i>	<i>Model, Series, Chassis # and Identifying Features</i>	
LR561	P	P	1	1988	LHD main, manual and automatic. From EA 320754 (manual) & EA 320338 (auto) to EA 351032 (both), LR# PRC6901	
LR565	P	P	1	1989	LHD main, manual and automatic. From FA 351033 to end of FA, LR# PRC7401	
LR521	P	P	1		Engine harness, no A/C - up to Suffix B, LR# 589113	
LR523	P	P	1		Engine harness for 25 ACR alt, with A/C, Suffix C up to 100782, LR# PRC2705	
LR522	P	P	1		Engine harness for 25 ACR alt, with A/C, 100783-on LR# PRC2706	
LR506	P	P	2		Rear harness with one interior light, up to Suffix D.	
LR510	P	P	2		Rear harness with 2 interior lights & wiper, no fogs. Suffix E up to 100782. LR# PRC1105	